

Fluoroalcohol-Treated Eye Shadow

Formula KEY-007B

(Twilight Shimmer)

Kobo Products - formulations

Part	Percent	Ingredients	INCI Name	Supplier
1	21.85	PF-5 TALC JA-46R	Talc (And) C9-15 Fluoroalcohol Phosphate	Kobo Products
	16.62	MAGNESIUM MYRISTATE	Magnesium Myristate	Kobo Products
	7.60	PF-5 SERICITE GMS-4C	Mica (And) C9-15 Fluoroalcohol Phosphate	Kobo Products
	5.32	BUB-11S2	Ultramarines (And) Triethoxycaprylylsilane	Kobo Products
	3.82	CL-2080	Polyethylene	Kobo Products
	3.82	BPD-500	HDI/Trimethylol Hexyllactone Crosspolymer (And) Silica	Kobo Products
	3.05	SP-10L	Nylon-12	Toray/Kobo Products
	0.07	PF-5 BLACK BL-100	Black Iron Oxides (And) C9-15 Fluoroalcohol Phosphate	Kobo Products
2	9.87	SS4267	Dimethicone (And) Trimethylsiloxysilicate	Momentive/Kobo Products
	0.77	Phenonip® XB	Phenoxyethanol (And) Methylparaben (And) Ethylparaben (And) Propylparaben	Clariant
3	9.42	KTZ® INTERVAL BLUE-11S2	Mica (And) Titanium Dioxide (And) Triethoxycaprylylsilane	Kobo Products
	2.68	KTZ® COPPER-11S2	Mica (And) Iron Oxides (C.I. 77491) (And) Triethoxycaprylylsilane	Kobo Products
4	15.11	KTZ® ULTRA SHIMMER	Mica (And) Titanium Dioxide	Kobo Products

100

Manufacturing Procedure

1. Using a Waring blender or Osterizer, grind Part 1 for two minutes to develop the color and disperse the powder ingredients.
2. Add the binder Part 2 to Part 1 dropwise while grinding at high speed for two minutes to aid complete distribution of the liquid coating the powders.
3. Add Part 3 color pearls and blend at high speed for two minutes to mix the pearl materials and coat them with binder.
4. Add Part 4 and grind for one minute only to blend in the shimmer particles.
5. Press into appropriate pans at 900-1000 psi.

Description

KTZ® Interval Blue-11S2 and KTZ® Copper-11S2 are Silane-treated Pearls which enhance smoothness. The Interference Blue Pearl reinforces the color. Additional Fluoroalcohol treatment of the Talc JA-46R and Sericite GMS-4C provide a base for the colors that is optimized for wear. Softness is derived from the addition of SP-10L. Polymeric Microspheres BPD-500 and CL-2080 add glide to the application upon skin. KTZ® Ultra Shimmer provides a slight glitter and foreground to the overall background of twilight.

Kobo Products, Inc.

3474 South Clinton Avenue, South Plainfield, NJ 07080 - USA
tel: +1 - 908-757-0033 fax: +1 - 908-757-0905 info@koboproductsinc.com

February, 2006

KOBO

www.koboproducts.com

Formulations

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

Use of Products

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

Patent Status

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

Limitation of Liability

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

The Powder & Dispersion Specialist

KOBO
www.koboproducts.com

Kobo Products, Inc.

3474 South Clinton Avenue
South Plainfield, NJ 07080 - USA
tel : +1 - 908-757-0033
fax : +1 - 908-757-0905

Kobo Products SAS

Rue Buissonnière. BP 67660
31676 Labege Cedex - FRANCE
tel : +33 - (0)5-62-88-77-40
fax : +33 - (0)5-62-88-77-49