

W/O Suncare Emulsion Featuring TNP50T7 &

Formula KSL-098B

TNP50ZSI

Kobo Products - formulations

Part	Percent	Ingredients	INCI Name	Supplier
1	31.93	Deionized Water	Water	
	0.56	Sodium Chloride	Sodium Chloride	Morton Salt
	0.20	Allantoin	Allantoin	ISP
2	31.90	TNP50T7	C12-15 Alkyl Benzoate (And) Titanium Dioxide (And) Alumina (And) Polyhydroxystearic Acid (And) Methicone	Kobo Products
	10.00	TNP50ZSI	C12-15 Alkyl Benzoate (And) Zinc Oxide (And) Polyhydroxystearic Acid (And) Triethoxycaprylylsilane	Kobo Products
	3.00	Hallbrite BHB	Butyloctyl Salicylate	C.P. Hall Company
	3.00	Floraesters® 15	Jajoba Esters	Florotech
	3.00	Cetiol® CC	Dicaprylyl Carbonate	Cognis Corp.
	3.00	ABIL® Wax 9801	Cetyl Dimethicone	Evonik
	2.50	Arlacel P135	PEG-30 Dipolyhydroxystearate	Croda
	2.50	ABIL® WE 09	Polyglyceryl-4 Isostearate (And) Cetyl PEG/PPG-10/1 Dimethicone (And) Hexyl Laurate	Evonik
	1.00	Argan Oil	Argania Spinosa Kernel Oil	Centerchem, Inc.
	1.00	Cetiol® SB 45	Shea Butter	Cognis Corp.
	0.20	Rosemary Oleoresin HQ 3401	Romarinus Officinalis (Rosemary) Leaf Extract	Hilltech
	0.15	Methyl Paraben NF	Methylparaben	International Sourcing
	0.06	Propyl Paraben NF	Propylparaben	International Sourcing
3	3.00	Iricalmin	Water (and) Triticum Vulgare (Wheat) Extract (and) Saccharomyces Cerevisiae Extract (and) Sodium Hyaluronate	Centerchem, Inc.
	3.00	Aculyn™ 44	PEG-150/Decyl Alcohol/SMDI Copolymer	Rohm & Haas
100				

Manufacturing Procedure

- Mix Part 1 in the order listed and heat to 70°C.
- Heat Part 2 to 70°C.
- Add Part 1 to Part 2 slowly with mixing.
- Cool the product slowly down to about 45°C and add Part 3, one ingredient at a time.
- Continue cooling and mixing emulsion to 33°C.

Description

This sunscreen is a W/O emulsion that uses a combination of inorganic sunscreens, Kobo's Titanium Dioxide Dispersion, TNP50T7, and Kobo's Zinc Oxide Dispersion, TNP50ZSI, to produce SPF for protection against UVB/UVA. The addition of moisturizers in the form of plant extracts and biopolymers helps to further condition the skin. The combination of Kobo's Titanium Dioxide and Zinc Oxide Dispersions gives excellent UVA protection and transparency on skin.

Notes

Active Ingredient(s)	
Titanium Dioxide	12.12%
Zinc Oxide	4.65%

Kobo Products, Inc.

3474 South Clinton Avenue, South Plainfield, NJ 07080 - USA
tel: +1 - 908-757-0033 fax: +1 - 908-757-0905 info@koboproductsinc.com

February, 2005

KOBO

www.koboproducts.com

Formulations

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

Use of Products

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

Patent Status

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

Limitation of Liability

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

The Powder & Dispersion Specialist

KOBO
www.koboproducts.com

Kobo Products, Inc.

3474 South Clinton Avenue
South Plainfield, NJ 07080 - USA
tel : +1 - 908-757-0033
fax : +1 - 908-757-0905

Kobo Products SAS

Rue Buissonnière. BP 67660
31676 Labege Cedex - FRANCE
tel : +33 - (0)5-62-88-77-40
fax : +33 - (0)5-62-88-77-49