



KCP-055A-BR

Moisturizing Concealer for the Eye Area

%	INGREDIENT	INCI NAME	SUPPLIER
Part 1			
39.10	Eutanol® G	Octyldodecanol	BASF
5.00	EB-21	Dibutyl Ethylhexanoyl Glutamide	Ajinomoto
4.00	GP-1	Dibutyl Lauroyl Glutamide	Ajinomoto
Part 2			
13.50	SALACOS® 99	Isononyl Isononanoate	Ikeda/Kobo Products
9.10	T.I.O.	Triethylhexanoin	Ikeda/ Kobo Products
8.10	BTD-ASGP3	Titanium Dioxide (CI 77891) (CI 77891) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	Kobo Products
4.00	GMS-ASG3	Mica (And) Stearoyl Glutamic Acid	Kobo Products
4.00	COSMOL™ 43V	Polyglyceryl-2 Triisostearate	Ikeda/Kobo Products
2.00	Plandool™-LG2	Phytosteryl/Octyldodecyl Lauroyl Glutamate	Nippon/Kobo Products
1.50	COSMOL™ 168ARV	Dipentaerythryl Hexahydroxystearate/Hexastearate/Hexarosinate	Ikeda/Kobo Products
1.40	BWYO-ASGP3	Iron Oxides (CI 77492) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	Kobo Products
1.00	KTZ® XIAN VISTAS	Titanium Dioxide (And) Mica (And) Iron Oxides (CI 77491)	Kobo Products
0.36	BWRO-ASGP3	Iron Oxides (CI 77491) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	Kobo Products
0.14	BWBO-ASGP3	Iron Oxides (CI 77499) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	Kobo Products
Part 3			
6.00	MSS-500-LL10	Silica (And) Lauroyl Lysine	Kobo Products
0.80	FLORITE R	Calcium Silicate	Kobo Products
100.00			

Description:

A stick concealer with moisturizing action for the eye area with good coverage and soft feel. SALACOS® 99 and T.I.O. are esters that help with spreadability and provide a nice after feel. COSMOL™ 43V is another excellent pigment dispersant. COSMOL™ 168ARV, a substitute for wool-derived lanolin with superior oxidative stability. GMS-ASGP4 gives a nice feel. KTZ® XIAN VISTAS imparts radiance. PLANDOOL™-LG2 provides moisture retention and improves skin barrier functions. Kobo's ASGP is a superdispersible, natural, hybrid treatment that gives a creamy feel and true color. Florite R, is a high oil-absorbing powder. MSS-500W-LL10 allows the formula to roll smoothly onto the skin while providing soft focus.

Manufacturing Procedure:

1. Heat Part 1 to 120-130°C
2. Cold to 80°C and add Part 2.
3. Mix until the pigments are completely dispersed.
4. Cold to 70-75°C and add Part 3.
3. Pour into containers at 70°C and leave to cool at RT.



KOBO
www.koboproducts.com

August, 2022

FORMULATIONS

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

USE OF PRODUCTS

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

PATENT STATUS

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

LIMITATION OF LIABILITY

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

KOBO

*The Powder & Dispersion
Specialist*



KOBO PRODUCTS, INC
3474 South Clinton Avenue
South Plainfield, NJ 07080
USA

Tel: +1 - 908 757 0033
Fax: +1 - 908 757 0905



KOBO BRASIL, LTDA
Rua Francisco Nakazato n. 2357
Itupeva SP 13.295-000
BRASIL

Tel: +55 (11) 5062 6034



KOBO PRODUCTS, LTD
67D(IV), Innovation Drive
Milton Park, Abingdon, OX14 4RQ
UNITED KINGDOM

Tel: +44 7913 636 673



KOBO PRODUCTS, SAS
135 Rue Buissonnière
Quartier Bouysset
31670 Labège
FRANCE

Tel: +33 - (0) 5 62 88 77 40
Fax: +33 - (0) 5 62 88 77 49



KOBO DISPATEK, INC
1-4-8 Nihombashi-bakurocho
Chuoko, Tokyo, 103-0002
JAPAN

Tel: +81 - 3 3663 8049
Fax: +81 - 3 3661 8679

www.koboproducts.com