



KLF-328A-EU

# Clean Beauty Fluid Foundation with ASGP's

%	INGREDIENT	INCI NAME	SUPPLIER
<b>Part 1</b>			
17.14	Neossance Hemisqualane	C13-15 Alkane	Centerchem
12.00	Emotion Light	Tripelargonin	Roelmi HPC
<b>Part 2</b>			
6.00	Bentone Luxe WO	Polyglyceryl-6 Polyricinoleate (and) Polyglyceryl-3 Diisostearate (and) Disteardimonium Hectorite	Elementis
<b>Part 3</b>			
9.35	<b>BTD-ASGP3</b>	Titanium Dioxide (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	<b>Kobo Products</b>
2.20	<b>BWYO-ASGP3</b>	Iron Oxides (CI 77492) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	<b>Kobo Products</b>
0.66	<b>BWRO-ASGP3</b>	Iron Oxides (CI 77491) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	<b>Kobo Products</b>
0.40	<b>BWBO-ASGP3</b>	Iron Oxides (CI 77499) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	<b>Kobo Products</b>
<b>Part 4</b>			
43.75	Distilled Water	Water	
2.00	Glycerin	Glycerin	-
1.70	Mg Sulfate Hept	Magnesium Sulphate Heptahydrate	Fisher Scientific
0.40	Symsave H	Hydroxyacetophenone	Symrise
0.40	SymDiol® 68	1,2 Hexanediol (and) Caprylyl Glycol	Symrise
<b>Part 5</b>			
2.00	<b>GMS-ASG3</b>	Mica (And) Stearoyl Glutamic Acid	<b>Kobo Products</b>
2.00	<b>CELLULOBEADS D-5-ASG3</b>	Cellulose (And) Stearoyl Glutamic Acid	<b>Kobo Products</b>
100.00			

## Description:

This silicone free, cold process, fluid w/o foundation, containing ASGP treated pigments, is very easy and quick to make. It gives a pleasant, quickly absorbed texture with a dewy finish. The ASGP treated pigments are able to be dispersed in situ into the emollients in around 1 minute and give the colour and coverage. CELLULOBEADS D-5-ASG3 and GMS-ASG3 both contribute to the soft and creamy sensory.

## Manufacturing Procedure:

1. Disperse Part 2 in Part 1 under Silverson tubular round hole head, until homogenous.
2. Add Part 3 and homogenise at 5000RPM around 1 min.
3. Prepare Part 4.
4. Make emulsion by adding Part 4 to Part 1 under propeller stirrer at 1000 RPM.
5. Homogenise at 3000 RPM for around 1 min.
6. Add Part 5 to the emulsion under propeller stirrer.



**KOBO**  
www.koboproducts.com

March, 2022

## FORMULATIONS

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

## USE OF PRODUCTS

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

## PATENT STATUS

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

## LIMITATION OF LIABILITY

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

# KOBO

*The Powder & Dispersion  
Specialist*



**KOBO PRODUCTS, INC**  
3474 South Clinton Avenue  
South Plainfield, NJ 07080  
USA

Tel: +1 - 908 757 0033  
Fax: +1 - 908 757 0905



**KOBO BRASIL, LTDA**  
Rua Francisco Nakazato n. 2357  
Itupeva SP 13.295-000  
BRASIL

Tel: +55 (11) 5062 6034



**KOBO PRODUCTS, LTD**  
67D(IV), Innovation Drive  
Milton Park, Abingdon, OX14 4RQ  
UNITED KINGDOM

Tel: +44 7913 636 673



**KOBO PRODUCTS, SAS**  
135 Rue Buissonnière  
Quartier Bouysset  
31670 Labège  
FRANCE

Tel: +33 - (0) 5 62 88 77 40  
Fax: +33 - (0) 5 62 88 77 49



**KOBO DISPATEK, INC**  
1-4-8 Nihombashi-bakurocho  
Chuoko, Tokyo, 103-0002  
JAPAN

Tel: +81 - 3 3663 8049  
Fax: +81 - 3 3661 8679

[www.koboproducts.com](http://www.koboproducts.com)