



KLF-358-EU

# The Ultimate Glow Foundation

%	INGREDIENT	INCI NAME	SUPPLIER
<b>Part 1</b>			
13.20	Emotion Light	Tripelargonin	Roelmi HPC
12.25	Neossance Hemisqualene	C13-C15 Alkane	Centerchem
3.00	Olivem 2090 G	Polyglyceryl-4 Oleate (and) Polyglyceryl-3 Polyricinoleate	Hallstar Beauty
3.00	Bentone Luxe XO	C13-15 Alkane (and) Distearidimonium Hectorite (and) Polyglyceryl-3 Polyricinoleate	Elementis
<b>Part 2</b>			
8.00	Dermol 20-SS	Octyldodecyl Stearoyl Stearate	Alzo International
2.00	<b>BTD-ASGP3</b>	Titanium Dioxide (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	<b>Kobo Products</b>
1.80	<b>BWYO-ASGP3</b>	Iron Oxides (CI 77492) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	<b>Kobo Products</b>
0.40	<b>BWRO-ASGP3</b>	Iron Oxides (CI 77491) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	<b>Kobo Products</b>
0.35	<b>BWBO-ASGP3</b>	Iron Oxides (CI 77499) (And) Stearoyl Glutamic Acid (And) Polyhydroxystearic Acid	<b>Kobo Products</b>
<b>Part 3</b>			
37.93	P.water	Deionized Water	
5.00	DUB DIOL	Methylpropanediol	Stearinerie Dubois
1.70	Mg Sulfate Hept	Magnesium Sulphate Heptahydrate	Fisher Scientific
0.40	SymDiol® 68	1,2-Hexanediol (and) Caprylyl Glycol	Symrise
0.40	Symsave® H	Hydroxyacetophenone	Symrise
0.07	Kelco-Care™ diutan gum	Sphingomonas Ferment Extract	CP Kelco
<b>Part 4</b>			
8.00	<b>KOBOPEARL® EF-8</b>	Mica (And) Titanium Dioxide (And) Barium Sulfate	<b>Kobo Products</b>
<b>Part 5</b>			
2.50	<b>CELLULOBEADS D-5-ASG3</b>	Cellulose (And) Stearoyl Glutamic Acid	<b>Kobo Products</b>
100.00			

## Description:

A foundation to provide sheer coverage, skin tone evening and a lit from within appearance without any sign of sparkly particles. Due to its thin consistency it can be filled in a dropper bottle to give it a serum skin-tint like application. Kobo's natural and superdispersible surface treated ASGP pigments provide the colour. KOBOPEARL® EF-8, a mica-based effect filler coated with titanium dioxide and barium sulphate is used to give that satin-glow in the formula. CELLULOBEADS D-5-ASG3 is used to impart a creamy and soft skin feel upon application.

## Manufacturing Procedure:

1. Combine Part 1 ingredients and homogenise under Silverson Square hole head for 5 min at 5000 RPM.
2. Combine Part 2 homogenise under Silverson Square hole head at 5000 RPM until pigments disperse and add to Part 1 and mix.
3. Prepare Part 3. Emulsify under propeller stirrer by adding Part 3 to Part 1 at 1000 RPM.
4. Add Part 4 under propeller stirring. Homogenise at 5000 RPM with Square hole head for 5 min.
5. Add Part 5 under propeller stirrer.



**KOBO**  
www.koboproducts.com

February, 2024

## FORMULATIONS

Product formulations are included as illustrative examples only. Kobo Products Inc. makes no representation or warranty concerning the efficacy or safety of any product manufactured using such formulations. All statements concerning the possible use of Kobo Products Inc. are for research purposes only. Responsibility for the performance or adequate testing of any product prior to sale or use of any such product lies with the manufacturer thereof.

## USE OF PRODUCTS

Products sold by Kobo are designed, manufactured and sold for industrial use only. Prior to use of any such product for any application other than an industrial use, the user has the sole responsibility and obligation to determine the suitability of any such product for any such application.

## PATENT STATUS

Nothing contained herein shall be construed to imply the nonexistence of any relevant patents or to constitute a permission, inducement or recommendation to practice any invention covered by any patent, without authority from the owner of the patent.

## LIMITATION OF LIABILITY

Kobo Products Inc. shall in no event, whether the claim is based on warranty, contract, tort, strict liability, negligence or otherwise, be liable for incidental or consequential damages, or for any other damages in excess of the amount of the purchase price.

# KOBO

## *The Powder & Dispersion Specialist*



**KOBO PRODUCTS, INC**  
3474 South Clinton Avenue  
South Plainfield, NJ 07080  
USA

Tel: +1 - 908 757 0033  
Fax: +1 - 908 757 0905



**KOBO BRASIL, LTDA**  
Rua Francisco Nakazato n. 2357  
Itupeva SP 13.295-000  
BRASIL

Tel: +55 (11) 5062 6034



**KOBO PRODUCTS, LTD**  
67D(IV), Innovation Drive  
Milton Park, Abingdon, OX14 4RQ  
UNITED KINGDOM

Tel: +44 7913 636 673



**KOBO PRODUCTS, SAS**  
135 Rue Buissonnière  
Quartier Bouysset  
31670 Labège  
FRANCE

Tel: +33 - (0) 5 62 88 77 40  
Fax: +33 - (0) 5 62 88 77 49



**KOBO DISPATEK, INC**  
1-4-8 Nihombashi-bakurocho  
Chuoko, Tokyo, 103-0002  
JAPAN

Tel: +81 - 3 3663 8049  
Fax: +81 - 3 3661 8679

[www.koboproducts.com](http://www.koboproducts.com)